



SEAT WALL

WHAT YOU'LL NEED

- Ladera Wall Blocks
- Stakes
- String line
- QUIKRETE® Construction Adhesive
- Heavy Duty Caulk Gun
- Paver Base
- Paver Sand
- Hand Tamp
- Torpedo Level

ITEM #				
Greystone	Revere	Granite	Eddington Blend	Charcoal Tan
11023034	11023078.REV	11023057	11023029	11023035

*STONE COLORS VARY BY REGION

How to build a seat wall with Ladera wall block



Map the preferred build area with a string line. Dig down to start building the foundation.



Add base, tamp and level with sand.



Lay the first course, making sure it's buried to provide a footer for your wall. Ensure level with torpedo level.



Apply QUIKRETE® Construction adhesive.



Place the next course, making sure to stagger the bond lines. Ensure level and repeat to preferred height.



There should be two lines of Ladera, per course. Make sure the flat edges meet in the middle at the seam.



Mortar in a natural stone seat.



Add lighting, and enjoy!



 **Submit your project!**
<https://www.pavestone.com/intake>





PARED DE ASIENTO

LO QUE NECESITARÁ

- Bloques para muro Ladera
- Estacas
- Línea de cuerda
- Adhesivo para construcción QUIKRETE®
- Pistola para calafateo para trabajo pesado
- Base para adoquines
- Arena para adoquines
- Pisón manual
- Nivel torpedo

ARTÍCULO

Greystone	Revere	Granite	Eddington Blend	Charcoal Tan
11023034	11023078.REV	11023057	11023029	11023035

*LOS COLORES DE PIEDRA VARIAN SEGÚN LA REGIÓN

Cómo Construir una Pared De Asiento con Bloques Ladera para Muro



Trace el área de construcción preferida con una línea de cuerda. Excave para comenzar a construir los cimientos.



Agregue la base, apisona y nivele con arena.



Coloque la primera hilera, asegurándose de enterrarla para que sirva de base al muro. Asegúrese de que esté nivelada con el nivel recto.



Aplique adhesivo para construcción QUIKRETE®.



Coloque la siguiente hilera, asegurándose de escalonar las líneas de unión. Asegúrese de que esté nivelada y repita hasta la altura preferida.



Debe haber dos líneas de Ladera por hilera. Asegúrese de que los bordes planos coincidan en el medio de la unión.



Aplique mortero en el asiento de piedra natural.



Agregue iluminación y disfrute.



 ¡Envía tu proyecto!
<https://www.pavestone.com/intake>

APRENDA MÁS

